

For application onto glass, the 'Wet Apply' method is recommended.

Thoroughly clean the glass. Ensure any traces of contaminants are removed. Particularly chemicals like ammonia from glass cleaners.

Spray the glass with clean water ideally with a few ml of mild detergent per litre (a capful of baby shampoo per litre is a good substitute for commercial application fluid).

DO NOT ALLOW THE WHITE BACKING PAPER TO BECOME WET.

Measure and mark the window to help positioning the graphic.

Remove the white paper backing from the graphic and lightly spray the adhesive side. An assistant is useful with large pieces.

Place the graphic on the glass, the water will allow you to 'snap' away from the glass and reposition.

Using a squeegee (a credit card can make a good substitute) start from the top centre and work the water out to the edges in a herringbone pattern, working down.

Peel back the application tape.

If the graphic is not adhering to the glass and insisting on staying on the application tape, rub it back onto the glass and leave for 15 mins and try again. The adhesive will activate and adhesion will improve.

Large bubbles can be pierced with a pin and the air/water gently worked out.

You will most probably have numerous smaller bubbles and these will disappear over the next couple of weeks as the adhesive cures and the vinyl tightens.